

## Day 1 Quick Reference

Image Selection Utility (Gradework 4D)	34, 117
Shader Support (AGTEK 4D) and Other Start-Up Options Menu Settings	36, 92
Status Bar Display Options in Entry Mode (Ctrl-Q / Q)	44, 77, 88, 246, 336
Length/Area Utility	58, 229
Move Point, Extend/Shorten Line Function (F7)	69, 107, 129, 241
Documentation Layer (AGTEK 4D)	72, 131
Display Pointer Snap Radius (Draw Snap Circle)	75, 119
Contour Streaming Entry	76
Adjustable Point Compression Utility	76, 86, 328, 340
Continue Last Entry Option (Right-Click Menu)	77, 128
Delete Segments from Data Line (Remove Selected Function)	85
Drag-Select Range of Scroll Points for Edits and Offsets	85, 136, 145, 331, 341, 343, 347
Contour Surface Utility	94, 160, 351
Assign Elevations by Daylight	104-105, 151, 157, 340
Move Start (Diamond) Point of Closed Object (Ctrl-M)	136
Swap Ends Utility (Ctrl-S)	142, 146, 198, 316
Assign Elevations by Slope	151, 343
Staged Design Option	164, 171, 192, 203, 208
Wildcard Label Selection	191, 338
Station Generator Utility	201, 333
Display Cut-Fill Map Colors as Background Image (Alt-K in Gradework 4D)	204
Display Region Hatching on Cut-Fill Maps	206
Export TXT or XLSX Volume Report for Excel	225, 228
Trim Lines Utility (Ctrl-T)	240, 329
Fillet Line Utility (Ctrl-F)	240, 346
Circle Utility	327, 339
Cut/Paste Surface Layer Data (AGTEK 4D)	334
Auto Pad Utility	337-338
Assign Elevations by Conform Utility	344